



№	Артикул	Наименование	К-во	№	Артикул	Наименование	К-во
1	XJ-001	Lock nut	2	26	XJ-026	Hexangular screw	2
2	XJ-002	Plain Washer	2	27	XJ-027	Spring washer	2
3	XJ-003	Fore-brush	2	28	XJ-028	Copper sleeve	2
4	XJ-004	Bearing	4	29	XJ-029	Outer-tire	2
5	XJ-005	Pulley	2	30	XJ-030	Driving wheel	2
6	XJ-006	Copper covering	2	31	XJ-031	Washer	2
7	XJ-007	Fore-brush belt	2	32	XJ-032	Handle plate	2
8	XJ-008	Pulley	3	33	XJ-033	Handle	1
9	XJ-009	Bearing	8	34	XJ-034	Handle-wheel	2
10	XJ-010	Wire Shield ring	4	35	XJ-035	Dustbin cover	1
11	XJ-011	Sheeting	2	36	XJ-036	Dustbin pedestal	1
12	XJ-012	Bearing bracket	2	37	XJ-037	Driving wheel belt	1
13	XJ-013	Torsion panel	4	38	XJ-038	Seal stripe	1
14	XJ-014	Pin	4	39	XJ-039	Lock nut	2
15	XJ-015	Bearing bracket	2	40	XJ-040	Washer	2
16	XJ-016	Column brush	2	41	XJ-041	Mid-adjusting handle wheel	2
17	XJ-017	Support Frame	1	42	XJ-042	Insulation sleeve	2
18	XJ-018	Spring	2	43	XJ-043	Bolt	2
19	XJ-019	Adjusting axle	2	44	XJ-044	Frame	1
20	XJ-020	Adjusting plate	2	45	XJ-045	Wheel	1
21	XJ-021	Cross bolt	20	46	XJ-046	Pin	2
22	XJ-022	Fore handle wheel	2	47	XJ-047	Cross Bolt	2
23	XJ-023	Bolt	2	48	XJ-048	Cross Bolt	10
24	XJ-024	Column brush belt	1				
25	XJ-025	Lid	2				